
OPERATOR'S MANUAL

FENDT

FENDT 8380 P

FENDT 8380 P AL

FENDT 8410 P

FENDT 8410 P AL



Operator's Manual for Fendt 8380 P / 8410 P Combine Series

1	General Information	11
1.1	Dear Customer	13
1.1.1	Preface	13
1.1.2	Company policy	13
1.1.3	Optional Extra	13
1.1.4	Spare parts and accessories	13
1.1.5	Warranty	14
1.1.6	Lubricants	14
1.2	Appropriate Use	15
1.2.1	Appropriate Use	15
1.2.2	Directives and standards	15
1.2.3	Statutory requirements	16
1.3	Placement of type and number plates	17
1.3.1	Combine CE markings, type and number plates	17
1.3.2	Product Identification	21
1.3.3	EC Declaration of Conformity for Combine and Table	22
1.4	Sectional Drawing, Parts Identification and Operational Description	27
1.4.1	Sectional Drawing and Parts Identification	27
1.4.2	Crop Processing	29
1.4.3	Feeding	30
1.4.4	Threshing	30
1.4.5	Separation	31
1.4.6	Cleaning	31
1.4.7	Grain Tank and Unloading	32
1.4.8	4-wheel drive	32
1.5	Ecology and environmental considerations	34
1.5.1	Important environmental issues	34
2	Safety	35
2.1	Safety	37
2.1.1	General Safety Precautions	37
2.1.2	Important guidelines and warning symbols	37
2.1.3	Safety precautions	38
2.1.4	Road Transport	40
2.1.5	Warning signs when driving on public roads	43
2.1.6	Field work	44
2.1.7	Maintenance work	46
2.1.8	Engine	49
2.1.9	Battery	51
2.1.10	Disposal	52
2.2	Safety decals	53
2.2.1	Warning/instruction decals on the machine	53
2.2.2	List of warning/instruction decals	65
2.3	Safety devices	72
2.3.1	Emergency Exit	72
2.3.2	Safety belts	73
2.3.3	Safety stop	74
2.3.4	Safety railings	75
2.3.5	Safety guards	76
2.3.6	Safety device for ladder	76
2.3.7	Trailer hitch	78
2.3.8	Wheel sprag and reversing alarm	79

2.3.9	Fire extinguisher and fire safety in the cab	80
2.4	Hydraulic System	81
2.4.1	Hydraulic systems - Hoses	81
2.5	Shafts	82
2.5.1	Weight distribution on the front and rear axle	82
3	Operation, Controls and Cab	83
3.1	Operator cab arrangement	85
3.1.1	Main components	85
3.1.2	Footrest	86
3.1.3	Refrigerator	86
3.1.4	Grain tank window	87
3.1.5	Sun visor	87
3.1.6	Cab storage	88
3.2	Safety Precautions - on the Move	89
3.2.1	Safety Precautions - on the Move	89
3.3	Starting and Stopping the Engine	90
3.3.1	Starting the Engine	90
3.3.2	Stopping the engine	92
3.4	Drive Controls	93
3.4.1	Steering Column	93
3.4.2	Brakes	95
3.4.3	Multifunction lever	97
3.4.4	Control panel	99
3.4.5	Adjustable armrest	104
3.4.6	Switch for road transport	105
3.5	Vario terminal	107
3.5.1	Explanation of icons	107
3.5.2	Interaction	124
3.5.3	Control panel	125
3.5.4	Machine settings	129
3.5.5	Residue discharge	133
3.5.6	Performance and returns	134
3.5.7	Yield measurement settings	135
3.5.8	Constant Flow	139
3.5.9	Grain handling	143
3.5.10	Table settings	144
3.5.11	Reel	147
3.5.12	Cutting height control	148
3.5.13	Preset cutting height	152
3.5.14	Field pressure	153
3.5.15	Crop system	154
3.5.16	Maintenance and calibration	155
3.5.17	Shaft speeds and shaft alarm calibration	157
3.5.18	System information and settings	159
3.5.19	Failure codes	163
3.5.20	Error code list	164
3.5.21	Guide	173
3.5.22	Data	175
3.5.23	Terminal settings	179
3.5.24	Info + information	183
3.5.25	Camera	186
3.5.26	Diagnostics system	187
3.6	Seats	189
3.6.1	Adjustment of Operator Seat	189
3.6.2	Instructor seat	190
3.7	Mirrors	191
3.7.1	Electrically Adjustable Rearview Mirrors	191
3.8	Accessibility	192
3.8.1	Ladder for Cab	192
3.8.2	Ladder for Engine Compartment	192
3.8.3	Cleaning the Windscreens	194

<https://www.ebooklibonline.com>

Hello dear friend!

Thank you very much for reading.

Enter the link into your browser.

The full manual is available for immediate download.

<https://www.ebooklibonline.com>

3.9	Light and Lamps	195
3.9.1	Lights	195
3.9.2	Lighting panel	196
3.10	Climate control	199
3.10.1	Controller	199
3.10.2	Components and functions	200
3.10.3	Overpressure and heat	201
4	Operation, Auto Level combine and table	203
4.1	Safety precautions	205
4.1.1	Safety precautions, operation of Auto Level Combine	205
4.1.2	Safety system - Alarms	205
4.2	Attachment of Auto Level Table	206
4.2.1	Attachment of table to Auto Level combine	206
4.3	Combinations	207
4.3.1	Automatic or Manual	207
4.3.2	Adjustment Combinations for Auto Level Combine and Auto Level Table ..	208
4.3.3	Priority of hydraulic functions	209
4.4	Auto Level combine	210
4.4.1	Auto Level combine	210
4.4.2	Manual Control of Auto Level Combine	210
4.5	Auto Level table	211
4.5.1	Principle of Auto Level Table	211
4.5.2	Using the Auto Level table	211
4.5.3	Bleeding	212
4.6	Auto Level Combine/Table	213
4.6.1	Combine	213
4.6.2	Transport	213
4.6.3	Auto Level table	214
4.7	Calibration	215
4.7.1	Calibration of Auto Level Combine	215
4.7.2	Calibration of Auto Level Table	216
4.7.3	Zero Cutting Height	216
4.7.4	Checking and Adjusting the Ground Sensors	217
4.8	Troubleshooting	218
4.8.1	Troubleshooting in General	218
4.8.2	Machine Not Levelling Correctly	218
4.9	Servicing and User Tips	220
4.9.1	Retrofit of new Auto Level job computer and sensors	220
4.9.2	Unintentional Use of Manual Keys in Automatic Mode	220
5	Cutting Tables	221
5.1	Safety precautions	223
5.1.1	Safety Precautions, Cutting Tables	223
5.2	Attachment/Removal of Table	224
5.2.1	Attachment of Table, Standard and Auto Level	224
5.2.2	Removal of Table	226
5.3	Table trailer	227
5.3.1	Attachment of Combine and Trailer	227
5.3.2	Table Trailer Brakes	227
5.4	Reel	228
5.4.1	Safety stop for reel	228
5.4.2	Reel Adjustment Up/Down, Fore/Aft	229
5.4.3	Bleeding	230
5.4.4	Rotation	231
5.4.5	Reel tine bars	231
5.4.6	Adjustment of the Reel in the Table	232
5.5	Knife	233
5.5.1	Knife and knife drive	233
5.6	Feeding	234
5.6.1	Table auger	234
5.6.2	Cut-off strip and distribution strip	235

5.6.3	Replacement of Feathering Fingers	236
5.6.4	Auger extensions	237
5.6.5	Reversing	238
5.7	Transmission	239
5.7.1	PowerFlow 18-30 ft cutting table, knife drive and table auger	239
5.7.2	Slip Clutch for Table Auger	239
5.8	PowerFlow Table	241
5.8.1	PowerFlow belts	241
5.8.2	Inspection and Start-Up of Powerflow Belts	242
5.8.3	Adjustment of belts	243
5.8.4	Scrapers, front	243
5.8.5	Rear Scrapers and Adjustment of Bearing Housings	244
5.8.6	Table Bottom	244
5.8.7	Cleaning	245
5.9	Crop lifters	246
5.9.1	Using Crop Lifters	246
5.10	Vertical Knives, Rape Auger and Straw Dividers	247
5.10.1	Vertical Knife	247
5.10.2	Mounting of Vertical Knife	248
5.10.3	Rape auger	248
5.10.4	Folding torpedo dividers and bow dividers	249
5.10.5	Mounting of Straw Dividers	249
5.10.6	Adjustment of Torpedo Divider	250
5.11	Fixed Table Auger Fingers	251
5.11.1	Fitting and using fixed table auger fingers	251
5.12	Main crop elevator	252
5.12.1	Elevator Chain	252
5.12.2	Elevator chain front shaft	252
5.12.3	Transmission for cutting table and feeding	253
5.12.4	Stone Trap	254
5.12.5	Preset cutting height sensor	255
6	Operation of Table and Threshing Unit	257
6.1	Safety precautions	259
6.1.1	Safety Precautions, Operation of Machine and Cutting Table	259
6.2	Operation of Table	260
6.2.1	Table Height and Table Automatic Control	260
6.2.2	Cutting height control	262
6.2.3	Field pressure control	263
6.2.4	Preset cutting height	264
6.2.5	Auto Level table	264
6.2.6	Table engagement	265
6.3	Operation of Threshing Mechanism	266
6.3.1	Threshing unit engagement	266
6.3.2	Cylinder Variator	266
6.3.3	Turning Tool for Cylinder	267
6.4	Concave Setting, Electrically Adjustable	268
6.4.1	Operation of concave	268
6.4.2	Concave Setting	268
6.5	Threshing	271
6.5.1	Concave filler plates	271
6.5.2	Straw walkers	271
6.5.3	Rear beater curtain	272
6.6	Straw Chopper and Spreader Hood	273
6.6.1	Straw chopper	273
6.6.2	Adjustment of spreader hood and straw deflectors	275
6.6.3	Counter Knives and Cross Bar	276
6.6.4	Replacement of Knives	278
6.7	Fanning Mill and Sieves	279
6.7.1	Fanning mill	279
6.7.2	Shaker shoe	280
6.7.3	Shaker Shoe with Electrical Sieves	281

6.7.4	Manual Adjustment of Sieves	281
6.7.5	Cleaning of Sieves and Main Grain Pan	282
6.7.6	Cleaning the Sieves	283
6.7.7	Shaker Shoe Light	284
6.7.8	Special Sieves	285
6.8	Internal Grain Transport	286
6.8.1	Returns system	286
6.8.2	Returns Volume Monitor	288
6.8.3	Filling system	289
6.8.4	Grain tank	290
6.8.5	Unloading system	292
6.9	Rotary Separator	294
6.9.1	Adjusting the Revolutions	294
6.9.2	Concave Setting	295
6.10	Straw hood	296
6.10.1	Alarm switch for straw hood blocked	296
6.11	Chaff spreader	297
6.11.1	Setting	297
6.12	Maize Threshing	299
6.12.1	Maize threshing in general	299
6.12.2	Attachment of Maize Header	299
6.12.3	Cutting height	299
6.12.4	Main crop elevator	299
6.12.5	Concave/initial settings	300
6.12.6	Threshing cylinder	300
6.12.7	Rotary Separator	300
6.12.8	Shaker shoe	301
6.12.9	Straw walkers	301
6.12.10	Scrapers	301
6.12.11	Rear beater curtain	302
6.12.12	Straw chopper	302
6.13	Harvest settings	303
6.13.1	Suggested harvest settings	303
6.13.2	Threshing directions	305
7	Adjustments	307
7.1	Safety precautions	309
7.1.1	Safety Precautions, Transmissions	309
7.2	Adjustment of Transmissions	310
7.2.1	General	310
7.2.2	Hydrostatic Transmission	310
7.3	Transmissions	311
7.3.1	Rear beater	311
7.3.2	Table and crop elevator	312
7.3.3	Straw chopper	313
7.3.4	Threshing cylinder	314
7.3.5	Unloading auger counter drive	315
7.3.6	Shaker Shoe and Chaff Spreader Counter Drive, and Straw Walker Drive	317
7.3.7	Returns system	318
7.3.8	Tank Filling Elevator and Tank Filling Auger	318
7.3.9	Dust aspirator	319
7.3.10	Rotary screen	319
7.3.11	Fanning mill	320
7.3.12	Rotary Separator	320
7.3.13	Alternator and fan	321
7.3.14	Climate control	321
7.3.15	The counter drive for the filling and returns system	322
7.4	Transmission Diagrams	323
7.4.1	Transmission Diagram, Left-Hand Side	323
7.4.2	Transmission Diagram, Right-Hand Side	326
7.4.3	Transmission Diagram, PowerFlow	328



Suggest:

For more complete manuals. Please go to the home page.

<https://www.ebooklibonline.com>

If the above button click is invalid. Please download this document first, and then click the above link to download the complete manual.

Thank you so much for reading

7.5	Adjustment of Brakes	330
7.5.1	Adjustment of Foot Brakes, Disc Brakes	330
7.5.2	Adjustment of parking brake	330
8	Engine	331
8.1	Safety precautions	333
8.1.1	Safety Precautions, Engine	333
8.2	Engines	334
8.2.1	Engine types	334
8.3	Air-Intake	335
8.3.1	Filter System	335
8.4	Cooling System	336
8.4.1	Rotary Screen and Dust Aspirator	336
8.4.2	Coolers	337
8.4.3	Coolant	338
8.4.4	Checking the fan belt tension	338
8.4.5	Checking the water pump belt	339
8.5	Fuel system	340
8.5.1	Fuel and quality requirements	340
8.5.2	Fuel system	341
8.5.3	Filter change	342
8.5.4	Bleeding the fuel system	343
8.6	SCR	344
8.6.1	The SCR system in general	344
8.6.2	Components and functions	345
8.6.3	Filling and storing DEF	346
8.6.4	Filter change	347
8.6.5	SCR system failure	347
8.7	Crankcase ventilation	348
8.7.1	Closed crankcase ventilation	348
8.8	Engine oil/change	349
8.8.1	Oil and Filter Change	349
8.9	Cleaning	351
8.9.1	Cleaning of engine compartment	351
8.9.2	Vibration damper	351
8.10	EEM4 engine control	352
8.10.1	Electronic engine monitoring	352
8.10.2	Engine Trouble Shooting (Self-Diagnosis)	353
9	Hydraulic system	355
9.1	Safety precautions	357
9.1.1	Safety Precautions, Hydraulic System	357
9.2	Hydraulic System	358
9.2.1	Hydraulic system	358
9.2.2	Storage of Hydraulic System	360
9.3	Hydrostatic system	361
9.3.1	Hydrostatic system	361
9.3.2	Hydrostatic servo steering	362
9.4	Auxiliary Hydraulics	363
9.4.1	Auxiliary hydraulics in general	363
9.4.2	Functions and Auxiliary Hydraulics	363
9.4.3	Reel hydraulics	363
9.4.4	Cutting table hydraulics	364
9.5	Oil and Filter Change	366
9.5.1	Draining and Filling Hydraulic Oil	366
9.5.2	Filter change in general	367
10	Electrical system	371
10.1	Safety precautions	373
10.1.1	Safety Precautions, Electric System	373
10.2	Electrical System	374
10.2.1	Charging System	374

10.2.2	Electric boxes, fuse test and main switch	374
10.2.3	Fuses and relays	376
10.2.4	External 12V connectors	381
10.3	Electro-Hydraulic System	384
10.3.1	Electro-Hydraulic System in General	384
11	Lubrication and Maintenance	385
11.1	Safety precautions	387
11.1.1	Safety Precautions, Maintenance	387
11.2	Tracks	389
11.2.1	Operational description for tracks	389
11.2.2	Maintenance of tracks	390
11.3	Lubrication Intervals	392
11.3.1	Lubrication chart, intervals	392
11.3.2	Lubrication chart, right- and left-hand sides	395
11.3.3	Lubrication chart, front axles	398
11.3.4	Lubrication points, left-hand machine side	399
11.3.5	Lubrication points, right-hand machine side	415
11.3.6	Lubricants and operating fluids	425
11.4	Maintenance Schedules	427
11.4.1	Preliminary service inspections	427
11.4.2	Maintenance required	428
11.5	Gear Oil Change	430
11.5.1	Gearbox	430
11.5.2	Final drives	430
11.5.3	Right-angle gear for returns thresher	431
11.6	Climate control	432
11.6.1	Maintenance	432
11.7	Moisture meter	433
11.7.1	Cleaning the moisture sensor	433
12	Off-season storage	435
12.1	Cleaning and Off-Season Storage	437
12.1.1	Off-season	437
12.1.2	Off-season storage	438
12.1.3	Storage of Engine, Fuel System, SCR System and Hydraulic System	438
12.1.4	Periodical Start-Up	439
12.1.5	Removal of Crop Elevator	439
12.1.6	Removal of Elevator Chains	440
12.1.7	Ordering spare parts	440
12.1.8	After Off-Season Storage	440
13	Optional Extra	441
13.1	Miscellaneous	443
13.1.1	Four-Wheel Drive	443
13.1.2	Extra camera	444
13.1.3	Table trailer	444
13.1.4	Guide system	445
13.1.5	Data - Doc Pro	445
13.1.6	AGCOMMAND	446
14	Specifications	447
14.1	Specifications	449
14.1.1	Dimensions and specifications	449
14.1.2	Specification table for tyres with equipment	458
	Alphabetical index	461

<https://www.ebooklibonline.com>

Hello dear friend!

Thank you very much for reading.

Enter the link into your browser.

The full manual is available for immediate download.

<https://www.ebooklibonline.com>