

JOHN DEERE
WORLDWIDE COMMERCIAL & CONSUMER
EQUIPMENT DIVISION

Professional Greensmower
2500A

OMTCU17234 J2

OPERATOR'S MANUAL



JOHN DEERE

⚠ WARNING: The Engine Exhaust from this product contains chemicals known to the State of California to cause cancer, birth defects or other reproductive harm.

California Proposition 65 Warning

⚠ WARNING: Diesel engine exhaust and some of its constituents are known to the State of California to cause cancer, birth defects, and other reproductive harm.

California Proposition 65 Warning

North American Version
Litho in U.S.A.

INTRODUCTION

Thank You for Purchasing a John Deere Product

We appreciate having you as a customer and wish you many years of safe and satisfied use of your machine.

Using Your Operator's Manual

This manual is an important part of your machine and should remain with the machine when you sell it.

Reading your operator's manual will help you and others avoid personal injury or damage to the machine.

Information given in this manual will provide the operator with the safest and most effective use of the machine.

Knowing how to operate this machine safely and correctly will allow you to train others who may operate this machine.

This manual and safety signs on your machine may also be available in other languages (see your John Deere dealer to order).

Sections in your operator's manual are placed in a specific order to help you understand all the safety messages and learn the controls so you can operate this machine safely. You can also use this manual to answer any specific operating or servicing questions. A convenient index located at the end of this book will help you to find needed information quickly.

The machine shown in this manual may differ slightly from your machine, but will be similar enough to help you understand our instructions.

RIGHT-HAND and LEFT-HAND sides are determined by facing in the direction the machine will travel when going forward. When you see a broken line arrow (----->), the item referred to is hidden from view.

Before delivering this machine, your dealer performed a predelivery inspection to ensure best performance.

Special Messages

Your manual contains special messages to bring attention to potential safety concerns, machine damage as well as helpful operating and servicing information. Please read all the information carefully to avoid injury and machine damage.



CAUTION: Avoid injury! This symbol and text highlight potential hazards or death to the operator or bystanders that may occur if the hazards or procedures are ignored.

IMPORTANT: Avoid damage! This text is used to tell the operator of actions or conditions that might result in damage to the machine.

NOTE: General information is given throughout the manual that may help the operator in the operation or service of the machine.

PRODUCT IDENTIFICATION

Record Identification Numbers

Greensmower

2500A PIN (010001 -)


If you need to contact an Authorized Service Center for information on servicing, always provide the product model and identification numbers.

You will need to locate the identification numbers for the product. Record the information in the spaces provided below.

DATE OF PURCHASE:


DEALER NAME:

DEALER PHONE:




MX18011

DIESEL ENGINE SERIAL NUMBER (C):



MX18009

PRODUCT IDENTIFICATION NUMBER (A):



MX18010

GAS ENGINE SERIAL NUMBER (B)

<https://www.ebooklibonline.com>

Hello dear friend!

Thank you very much for reading.

Enter the link into your browser.

The full manual is available for immediate download.

<https://www.ebooklibonline.com>

TABLE OF CONTENTS

Safety	1
Operating - Machine	11
Operating - Cutting Units	23
Replacement Parts	34
Service Intervals	35
Service Lubrication	37
Service Engine	40
Service Transmission	55
Service Hydraulics	58
Service Cutting Units	62
Service Electrical	71
Service Miscellaneous	76
Troubleshooting	79
Storage	85
Assembly	87
Specifications	93
Warranty	97
Index	101

All information, illustrations and specifications in this manual are based on the latest information at the time of publication. The right is reserved to make changes at any time without notice.

COPYRIGHT© 2003
Deere & Co.
John Deere Worldwide Commercial and
Consumer Equipment Division
All rights reserved
Previous Editions
COPYRIGHT©

OMTCU17234 J2 - English

SAFETY

Understanding The Machine Safety Labels




MIF

The machine safety labels shown in this section are placed in important areas on your machine to draw attention to potential safety hazards.

On your machine safety labels, the words DANGER, WARNING, and CAUTION are used with this safety-alert symbol. DANGER identifies the most serious hazards.

The operator's manual also explains any potential safety hazards whenever necessary in special safety messages that are identified with the word, CAUTION, and the safety-alert symbol.

DANGER




MX18013, M95786

Picture Note: Two safety labels attached to each cutting reel.

To avoid injury from rotating blades, stay clear of reel.

Shut off engine before servicing, lubricating or removing cutting unit.


WARNING



MX18013, M95785A

To avoid injury, avoid quick stops and reduce speed on slopes.

CAUTION



MX18013, MT5191

HELP AVOID INJURY

- Operator training required.
- Read operator's manual.
- Keep shields in place.
- Never carry riders.
- Keep people a safe distance away.
- Maintain all safety devices.
- Before leaving machine:
 - Stop engine.
 - Set park brake.

SAFETY

the engine and sold as stated above in the geographic areas governed by the regulating agencies.

NOTE: The hp/kW rating on the engine emissions certification label specifies the gross engine hp/kW, which is flywheel power without fan. In most applications this will not be the same rating as the advertised vehicle hp/kW rating.

Emission Control System Certification Label (Small Off-Road Gas Engines)

NOTE: Tampering with emission controls and components by unauthorized personnel may result in severe fines or penalties. Emission controls and components can only be adjusted by EPA and/or CARB authorized service centers. Contact your John Deere Commercial and Consumer Equipment Retailer concerning emission controls and component questions.

The presence of an emissions label signifies that the engine has been certified with the United States Environmental Protection Agency (EPA) and/or California Air Resources Board (CARB).

The emissions warranty applies only to those engines marketed by John Deere that have been certified by the EPA and/or CARB; and used in the United States and Canada in off-road mobile equipment.

Emission Compliance Period (Small Off-Road Gas Engines)

If your engine has the emission compliance category listed on the emission control system certification or air index label, this indicates the number of operating hours for which the engine has been certified to meet EPA and/or CARB emission requirements. The following table provides the engine compliance period in hours associated with the category found on the certification label.

Agency	Category	Hours
EPA	C	250
EPA	B	500
EPA	A	1000
CARB	Moderate	125
CARB	Intermediate	250
CARB	Extended	500

Canadian Electromagnetic Compatibility (EMC) Compliance

This spark ignition system complies with Canadian ICES-002.

Operator Training Required

- The owner of the machine is responsible for training the users of the machine.
- The owner/user can prevent accidents with proper use of the machine. The owner/user is responsible for accidents or injuries occurring to themselves, other people or property.
- Do not allow operation of the machine by untrained persons.
- Read the operator manual and study the safety and operation sections before operating the machine.
- If the operator of the machine cannot read or understand this manual, the machine owner is responsible to explain this material to the operator. This publication is available in other languages.
- Operate the machine in an open, unobstructed area under the direction of an experienced operator.
- Learn the use of all controls.
- Operator practice is required to learn the moving, stopping, turning and other operating characteristics of the machine.

Operating Safely

- Only allow responsible adults, who are familiar with the instructions to operate the machine. Local restrictions may restrict the age of the operator.
- Inspect machine before you operate. Be sure hardware is tight. Repair or replace damaged, badly worn, or missing parts. Replace faulty silencers. Be sure guards and shields are in good condition and fastened in place. Make any necessary adjustments before you operate.
- Before using, always visually inspect to see that the blades, blade bolts and the mower assembly are not worn and damaged. Replace worn and damaged blades and bolts in sets to preserve balance.
- Be sure all drives are in neutral and parking brake is locked before starting engine. Only start engine from the operator's position.
- Do not change the engine governor settings or overspeed the engine. Operating the engine at excessive speed can increase the hazard of personal injury.

SAFETY

- Do not operate mower without discharge chute or entire grass catcher in place. Never operate with the discharge deflector raised, removed, or altered, unless using a grass catcher.
- Check brake action before you operate. Adjust or service brakes as necessary.
- Stop machine if anyone enters the area.
- If you hit an object or if abnormal vibration occurs, stop and inspect the machine. Make repairs before you operate. Keep machine and attachments properly maintained and in good working order.
- Be aware of the mower discharge direction and make sure that no one is in the path of the discharge direction.
- Do not leave machine unattended when it is running.
- Only operate during daylight or with good artificial light.
- Stop the blades rotating before crossing surfaces other than grass.
- Use only accessories and attachments approved by the manufacturer of the machine. Keep safety labels visible when installing accessories and attachments.
- Do not operate machine if you are under the influence of drugs or alcohol.
- Check before each use that operator presence controls are functioning correctly. Test safety systems. Do not operate unless they are functioning correctly.
- Always wear seat belt if machine has a standard ROPS or a folding ROPS in the upright position.
- Never raise mower decks when blades are running.
- Slow down and be careful of traffic when operating near or crossing roadways. Stop blades before crossing roads or sidewalks. Use care when approaching blind corners, shrubs, trees, or other objects that may obscure vision.
- Do not wear radio or music headphones. Safe service and operation require your full attention.
- Disengage drive to attachments when transporting or not in use.
- Reduce the throttle setting during engine run-out and, if the engine is provided with a fuel shut-off valve, turn the fuel off at the conclusion of mowing.
- When machine is left unattended, stored, or parked, lower the mower deck unless a positive mechanical lock is used.

Using a Spark Arrestor

The engine in this machine is not equipped with a spark arrestor muffler. It is a violation of California Public Resource Code Section 4442 to use or operate this engine


on or near any forest-covered, brush-covered or grass-covered land unless the exhaust system is equipped with a spark arrestor meeting any applicable local or state laws. Other states or federal areas may have similar laws.

A spark arrestor for your machine may be available from your authorized dealer. An installed spark arrestor must be maintained in good working order by the operator.

Parking Safely

- Stop machine on a level surface, not on a slope.
- Move the Mow/Transport lever to the TRANSPORT position to disengage reels.
- Push the Raise/Lower lever forward to lower the cutting units.
- Lock park brake.
- Stop engine.
- Remove key.
- Before you leave the operator's location, wait for engine and all moving parts to stop.

Checking Mowing Area



MIF

- Evaluate the terrain to determine what accessories and attachments are needed to properly and safely perform the job.
- Clear mowing area of objects that might be thrown. Keep people and pets out of mowing area.
- Low-hanging branches and similar obstacles can injure the operator or interfere with mowing operation. Before mowing, identify potential obstacles such as low-hanging branches, and trim or remove those obstacles.
- Study mowing area. Set up a safe mowing pattern. Do not mow where traction or stability is doubtful.
- Test drive area with mower lowered but not running.

SAFETY


Slow down when you travel over rough ground.

Protect Children:

Rotating Blades are Dangerous

Help Prevent Serious Or Fatal Accidents:

- Rotating blades can cut off arms and legs, and throw objects. Failure to observe safety instructions could result in serious injury or death.
- Keep hands, feet and clothing away from attachment when engine is running.
- Be alert at all times, drive forward carefully. People, especially children can move quickly into the mowing area before you know it.
- Before backing up, shut off PTO and look down and behind the machine carefully, especially for children.
- Do not mow in reverse.
- Shut off blades when you are not mowing.
- Park machine safely before leaving the operator's station for any reason including emptying the grasscatchers or unplugging the chute.




MX18014

- Never assume that children will remain where you last saw them. Children are attracted to machine activity, stay alert to the presence of children.
- Keep children out of the area when you are operating. Turn the machine off if a child enters the mowing area.
- Use extra care when you come to blind corners, shrubs, trees, or other objects that may block your vision.
- Do not let children or an untrained person operate the machine.
- Do not carry or let children ride on machine or any attachment even with the blades off. Do not tow children in a cart or trailer.


SAFETY

Avoid Tipping



- Slopes are a major factor related to loss-of-control and tip-over accidents, which can result in severe injury or death. All slopes require extra caution. If you cannot back up the slope or if you feel uneasy on it, do not mow it.
- Drive up and down a hill - not across.
- Do not mow or operate on slopes you cannot back up.
- Keep all movement on slopes slow and gradual. Do not make sudden changes in speed or direction.
- Use a slow speed when operating on a slope. Choose a low gear or speed so that you will not have to stop or shift while on the slope.
- Tires may lose traction on slopes even though the brakes are functioning properly.
- Do not turn on slopes unless necessary. Turn slowly and turn downhill. Do not shift to neutral and coast downhill.
- Stay alert for holes and other hidden hazards in the terrain. Uneven terrain could overturn the machine. Tall grass can hide obstacles.
- Keep away from drop-offs, ditches and embankments. The machine could suddenly turn over if a wheel is over the edge of a cliff or ditch, or if an edge caves in.
- Use extra care with grass catchers or other attachments. These can change the stability of the machine. Do not use grass catcher on steep slopes.
- Follow the manufacturer's recommendations for wheel weights or counterweights for added stability when operating on slopes or using front or rear mounted attachments. Remove weights when not required.
- Do not stop when going up hill or down hill. If machine stops going up hill or tires lose traction, disengage mower blades and back down slowly.
- Operating machine when grass is wet can cause reduced traction and sliding.
- Do not try to stabilize the machine by putting your foot on the ground.

Wear Appropriate Clothing




MIF

- Wear close fitting clothing and safety equipment appropriate for the job.
- Always wear safety goggles, or safety glasses with side shields, and a hard hat when operating the mower.
- Wear a suitable protective device such as earplugs. Loud noise can cause impairment or loss of hearing.

Keep Riders Off

- Only allow the operator on the machine. Keep riders off.
- Riders on the machine or attachment may be struck by foreign objects or thrown off the machine causing serious injury.
- Riders obstruct the operator's view resulting in the machine being operated in an unsafe manner.

Mount and Dismount Safely




MX18015

SAFETY

- Do not step on pedals when mounting or dismounting.
- Keep step area and platform clean.
- Stop machine, move Mow/Transport lever to transport position, lower cutting units to the ground, lock park brake, stop engine, remove key, and wait for all moving parts to stop before dismounting.

Transport Safely



MIF

- Use safety lights and devices. Slow-moving machines when driven on public roads are hard to see, especially at night. Avoid personal injury or death resulting from a collision with a vehicle.
- Flashing warning lights are recommended whenever driving on public roads to increase visibility. Extra flashing warning lights may need to be installed.

Checking Wheel Bolts

- A serious accident could occur causing serious injury if wheel bolts are not tight.
- Check wheel bolt tightness often during the first 100 hours of operation.
- Wheel hardware must be tightened to specified torque using the proper procedure anytime it is loosened.

Avoid Neutral Creep

- The machine may creep forward or backward while in neutral with engine running.
- After engine has started, unlock park brake and with directional speed control speed pedals centered, machine should not move.
- If movement is evident, neutral return mechanism is adjusted incorrectly.

Avoid High Pressure Fluids



MIF

- Hydraulic hoses and lines can fail due to physical damage, kinks, age, and exposure. Check hoses and lines regularly. Replace damaged hoses and lines.
- Hydraulic fluid connections can loosen due to physical damage and vibration. Check connections regularly. Tighten loose connections.
- Escaping fluid under pressure can penetrate the skin causing serious injury. Avoid the hazard by relieving pressure before disconnecting hydraulic or other lines. Tighten all connections before applying pressure.
- Search for leaks with a piece of cardboard. Protect hands and body from high pressure fluids.
- If an accident occurs, see a doctor immediately. Any fluid injected into the skin must be surgically removed within a few hours or gangrene may result. Doctors unfamiliar with this type of injury should reference a knowledgeable medical source. Such information is available from Deere & Company Medical Department in Moline, Illinois, U.S.A. Information may be obtained in the United States and Canada only by calling 1-800-822-8262.

Practice Safe Maintenance



MIF

- Only qualified, trained adults should service this


SAFETY

machine.

- Understand service procedure before doing work. Keep area clean and dry.
- Do not operate the engine in a confined space where dangerous carbon monoxide fumes can collect.
- Never lubricate, service, or adjust machine while it is moving. Keep safety devices in place and in working condition. Keep hardware tight.
- On multi-bladed machines, take care as rotating one blade can cause other blades to rotate.
- Keep hands, feet, clothing, jewelry, and long hair away from any moving parts, to prevent them from getting caught.
- Lower attachments to the ground before cleaning or servicing machine. Disengage all power and stop the engine. Lock park brake and remove the key. Let machine cool.
- Disconnect battery or remove spark plug wire (for gasoline engines) before making any repairs.
- Before servicing machine, carefully release pressure from any components with stored energy, such as hydraulic components.
- Keep all nuts and bolts tightened, especially blade attachment bolts.
- Securely support any machine elements that must be raised for service work. Use jack stands or lock service latches to support components when needed.
- Never run engine unless park brake is locked.
- Use care when checking blades. Wrap blades or wear gloves and use caution when servicing them. Only replace blades. Never straighten or weld them.
- Keep all parts in good condition and properly installed. Fix damage immediately. Replace worn or broken parts. Replace all worn or damaged safety and instruction decals.
- Grass catcher components are subject to wear, damage, and deterioration which could expose moving parts or allow objects to be thrown. Check components frequently and replace with manufacturer's recommended parts when necessary.
- To prevent fires, remove any buildup of grease, oil, or debris from the machine, especially the engine compartment.
- Charge batteries in an open, well-ventilated area, away from sparks. Unplug battery charger before connecting or disconnecting from the battery. Wear protective clothing and use insulated tools.
- Do not modify machine or safety devices. Unauthorized modifications may impair its function and safety.

- Check brake operation frequently. Adjust and service as needed.

Prevent Fires



MIF

- Never remove fuel cap, or add fuel with engine running or hot. Allow engine to cool for several minutes.
- Never store equipment with fuel in the tank inside a building where fumes may reach an open flame or spark.
- Allow engine to cool before storing in any enclosure.
- To reduce fire hazard, keep engine free of grass, leaves, or excessive grease.

Tire Safety

Explosive separation of a tire and rim parts can cause serious injury or death:



MIF

- Do not attempt to mount a tire without the proper equipment and experience to perform the job.
- Always maintain the correct tire pressure. Do not inflate the tires above the recommended pressure. Never weld or heat a wheel and tire assembly. The heat can cause an increase in air pressure resulting in a tire explosion. Welding can structurally weaken or deform the wheel.

SAFETY

- When inflating tires, use a clip-on chuck and extension hose long enough to allow you to stand to one side and NOT in front of or over the tire assembly.
- Check tires for low pressure, cuts, bubbles, damaged rims or missing lug bolts and nuts.

Handling Fuel Safely

Fuel and fuel vapors are highly flammable:




- Do not refuel machine while you smoke, when machine is near an open flame or sparks, or when engine is running. Stop engine and allow to cool before filling.
- Never remove the fuel cap or add fuel with the engine running.
- Replace all fuel tanks and container caps securely.
- Never fill fuel tank or drain fuel from a machine in an enclosed area. Fill fuel tank outdoors.
- Prevent fires. Clean up spilled fuel immediately. If fuel is spilled on clothing, change clothing immediately. Do not attempt to start the engine but move the machine away from the area of spillage and avoid creating any source of ignition until fuel vapors have dissipated.
- Do not store fuel in container or machine with fuel in tank in a building where fumes may reach an open flame or spark.
- Prevent fire and explosion caused by static electric discharge. Use only non-metal, portable fuel containers approved by the Underwriter's Laboratory (U.L.) or the American Society for Testing & Materials (ASTM). If using a funnel, make sure it is plastic and has no screen or filter.



- Static electric discharge can ignite gasoline vapors in an ungrounded fuel container. Remove the fuel container from the bed of a machine or trailer or the trunk of a car and place on the ground away from the machine before filling. Keep nozzle in contact with container opening while filling. Do not use a nozzle lock-open device.
- When practical, remove equipment from trailers or truck beds and refuel them on the ground. If this is not possible, use a portable, plastic fuel container to refuel equipment on a truck bed or trailer.
- For gasoline engines, do not use gas with methanol. Methanol is harmful to your health and to the environment.

Handling Waste Product and Chemicals

Waste products, such as, used oil, fuel, coolant, brake fluid, and batteries, can harm the environment and people:



MIF

- DO NOT use beverage containers for waste fluids - someone may drink from them.
- See your local Recycling Center or John Deere dealer to learn how to recycle or get rid of waste products.
- A Material Safety Data Sheet (MSDS) provides specific details on chemical products: physical and health hazards,

SAFETY

safety procedures, and emergency response techniques.
The seller of the chemical products used with your machine
is responsible for providing the MSDS for that product.

OPERATING - MACHINE


Daily Operating Checklist

- Test safety systems.
- Check tire pressure.
- Check fuel level.
- Check engine oil level.
- Check hydraulic oil level.

Avoid Damage to Plastic and Painted Surfaces

- Do not wipe plastic parts unless rinsed first.
- Insect repellent spray may damage plastic and painted surfaces. Do not spray insect repellent near machine.
- Be careful not to spill fuel on machine. Fuel may damage surface. Wipe up spilled fuel immediately.


Pedestal Controls



M97303

- A - Tilt Steering Adjustment Handle**
- B - Choke Knob (Gas Model)**


Console Controls



MX18003

- A - Key Switch**
- B - Glow Plug Indicator Light (Diesel Model)**
- C - Indicator Lights**
- D - Raise/Lower Lever**
- E - Mow/Transport Lever**
- F - Throttle Control Lever**
- G - Leak Detector Indicator Light (Optional)**

Foot Platform Controls




M97302

- A - Park Brake Pedal/Emergency Brake**
- B - Park Brake Lock**
- C - Forward Travel Pedal**
- D - Reverse Travel Pedal**

OPERATING - MACHINE


Miscellaneous Controls



M97305, M97389

- A - Seat Adjustment Lever
- B - Fuel Gauge


Adjusting Operator Seat



M97305

1. Sit on the seat and pull lever (A) to the left.
2. Slide seat forward or backward to desired position.
3. Release lever.

Adjusting Tilt Steering Wheel



M97366


1. Raise and hold adjustment T-handle (A).
2. Move steering wheel to desirable operating position.
3. Lower T-handle to lock steering wheel in position.

Adjusting Mowing Speed

NOTE: Greensmower is preset at the factory to operate at approximately 7.1 km/h (4.4 mph).

Wheel RPM's necessary to meet the preset mow speed specification are 168 to 192. Wheel RPM's have been preset at the factory to assure proper forward mow speed regardless of tire size.

1. Park the machine safely. (See Parking Safely in the SAFETY section.)




M97395

2. Locate mow speed adjustment (A).
3. Move Mow/Transport lever to the MOW position.

OPERATING - MACHINE

NOTE: Preliminary dimension (B) between top of mow speed adjustment and bottom of forward travel pedal linkage is 22mm (0.87 in.) When mow speed adjustments change, record any dimension (B) changes for future reference.




M97396

4. Loosen jam nuts (C).
5. Adjust stop dimension.
 - Increase dimension (B) for increased mowing speed.
 - Decrease dimension (B) for decreased mowing speed.
6. Tighten jam nuts.
7. Move Mow/Transport lever to the TRANSPORT position.
8. Measure off 30.5 m (100 ft.)
9. Start engine.
10. Move Mow/Transport lever to the MOW position.
11. Move throttle lever to the FAST position. Depress FORWARD travel pedal fully.
12. Record the number of seconds it takes to travel the 30.5 m (100 ft.) length.
13. Refer to applicable cutting ratio table to determine ground speed and frequency of cut.
14. Continue adjustment process until desired mowing speed and frequency of cut is achieved.

Cutting Ratios

Ground Speed	Seconds to Travel 30.5m (100 ft)	Frequency of Cut	
		7 Blade	11 Blade
4 km/h (2.5 mph)	27.2	4.37 mm (.172 in.)	2.77 mm (.109 in.)
4.8 km/h (3.0 mph)	22.7	5.23 mm (.206 in.)	3.33 mm (.131 in.)
5.6 km/h (3.5 mph)	19.5	6.1 mm (.240 in.)	3.89 mm (.153 in.)
6.4 km/h (4.0 mph)	17.0	6.98 mm (.275 in.)	4.45 mm (.175 in.)
7.2 km/h (4.5 mph)	15.2	7.85 mm (.309 in.)	4.98 mm (.196 in.)

Testing Safety Systems



CAUTION: Avoid injury! Engine exhaust fumes contain carbon monoxide and can cause serious illness or death.

Move the machine to an outside area before running the engine.

Do not run an engine in an enclosed area without adequate ventilation.

- Connect a pipe extension to the engine exhaust pipe to direct the exhaust fumes out of the area.
- Allow fresh outside air into the work area to clear the exhaust fumes out.

The safety systems installed on your machine should be

OPERATING - MACHINE

checked before each machine use. Be sure you have read the machine operator manual and are completely familiar with the operation of the machine before performing these safety system checks.

Use the following checkout procedures to check for normal operation of machine.

If there is a malfunction during one of these procedures, do not operate machine. **See your authorized dealer for service.**

Perform these tests in a clear open area. Keep bystanders away.

Testing Mow-Transport Lever Switch

Test 1

1. Sit on seat.
2. Lock the park brake.
3. Put transmission in NEUTRAL.
4. Move Mow/Transport lever to the MOW position.
5. Turn key switch to the START position.

Result: Engine must not start. If engine starts, there is a problem with your safety interlock circuit.

NOTE: Move Mow/Transport lever to the TRANSPORT position and turn the key to the STOP position before starting engine.

Test 2

1. Sit on seat.
2. Lock the park brake.
3. Put transmission in NEUTRAL.
4. Raise off seat.
5. Start engine.
6. Lower cutting units to the ground.
7. Move Mow/Transport lever to the MOW position.

Result: Engine must stop within two seconds with no rotation of cutting reels. If engine does not stop, there is a problem with your safety interlock circuit.

Testing Raise/Lower Lever Switch

1. Sit on seat.
2. Lock the park brake.
3. Move Mow/Transport lever to the TRANSPORT position.
4. Start engine.

5. Unlock the park brake.
6. Put the transmission in neutral.
7. Lower cutting units with the Raise/Lower lever.
8. Move Mow/Transport lever to the MOW position.

Result: Cutting reels must not rotate. If reels rotate, there is a problem with your safety interlock circuit.

Testing Seat Switch

Test 1

1. Sit on seat.
2. Lock the park brake.
3. Move Mow/Transport lever to the TRANSPORT position.
4. Start engine.
5. Unlock the park brake.
6. Put transmission in neutral.
7. Move Mow/Transport lever to the MOW position.



CAUTION: Avoid injury! Blades are sharp and rotate quickly:

- Keeps hands and feet away from cutting reels while machine is running.
- Always wear gloves while working on cutting reels.
- Watch for rotation of cutting reels. Rotating one cutting reel can cause another blade or cutting reel to rotate.

8. Push the Raise/Lower lever forward. Cutting reels should start rotating.

9. Raise off seat.

Result: Engine must stop within two seconds and reels should stop rotating. If engine does not stop, there is a problem with your safety interlock circuit.

Test 2

1. Sit on seat.
2. Lock the park brake.
3. Start engine.
4. Unlock the park brake.
5. Put the transmission in neutral.
6. Move Mow/Transport lever to the TRANSPORT position.
7. Raise off seat.

Result: Engine must stop within two seconds. If engine



Suggest:

If the above button click is invalid.

Please download this document

first, and then click the above link

to download the complete manual.


Thank you so much for reading

OPERATING - MACHINE

does not stop, there is a problem with your safety interlock circuit.

Using Park Brake

Locking The Park Brake:



M97302

1. Push and hold brake pedal (A) down.
2. Push park brake lock (B) down.
3. Release brake pedal.
4. Release park brake lock. Brake pedal should stay down and park brake lock should stay locked.

Unlocking The Park Brake:

1. Push brake pedal (A) down. Park brake lock (B) should release immediately.
2. Release brake pedal.

Glow Plug

NOTE: Glow plugs preheat the combustion chamber for better starting performance.


1. Turn key switch to the RUN position.



MX14996

- The amber glow plug indicator light (A) should go on.
 - The indicator light should go off in approximately three seconds after the key switch is turned to the RUN position.
2. Turn the key switch to the START position to start the engine.

Using the Raise/Lower Lever



MX14997

1. Push Raise/Lower lever (A) forward to lower cutting reels.
 - If the Mow/Transport lever (B) is in the MOW position, the cutting reels will begin to rotate.
 - If the Mow/Transport lever is in the TRANSPORT position, the cutting units will lower but the reels will not rotate.
2. Pull lever (A) rearward to raise cutting units.
 - If the Mow/Transport lever is in the MOW position, the cutting reels will stop rotating.

<https://www.ebooklibonline.com>

Hello dear friend!

Thank you very much for reading.

Enter the link into your browser.

The full manual is available for immediate download.

<https://www.ebooklibonline.com>